



Microcystin Lateral Flow Kit

QUICK REFERENCE GUIDE

1 Collect

Collect water sample.



2 Draw

Fill syringe plunger with water sample.



3 Filter

Filter water from syringe plunger while dispensing into tube.



4 Cap & mix

Place cap onto the tube and mix for 10 seconds.

⌚ 10 seconds



5 Load cassettes

5A Pour the contents of the Sample Dilution Buffer tube into the reservoir on the cassette.

5B Pour contents of Negative Control tube onto second cassette (*this is the control test*).

5A · Sample



5B · Control



6 Read results

Wait 10 minutes for results.

⌚ 10 minutes

